

Tips for laying bricks in cold conditions

MUST DO'S

- Mortar Mix should be 6:1:1 (Per Building Code of Australia)
- 6 Parts sand
- 1 Part Lime https://www.cementaustralia.com.au/products/lime
- 1 Part Cement Cement during winter should be "Early High Strength" Cement Australia sell this all year round but in Tassie during winter this is what their GP cement is. Boral also make one. Other cement types will all take longer to set so BEWARE.
- Bricks come to site dry, ensure they are covered up well on site to keep dry at all times.
- Using cold/damp/wet bricks, cold sand and cold water it's going to take longer for mortar to set. The drier and warmer everything is, the faster it will set.
- Cover up brickwork at the completion of a day where possible per above.
- Use dry sand try to keep it covered.

ADDITIONAL MEASURES

- An accelerator is available from Island Block (250ml of Sika Set Accelerator per 10 kg of cement)
- Add hot water to the mortar mix where possible. Warm water in lieu of freezing cold water will accelerate the curing process.

HEAD OFFICE

ISLAND BLOCK & PAVING

Midland Highway, Breadalbane, Tasmania 7300

Phone: (03) 6398 2088

ISLAND BLOCK & PAVING

41 Howard Road, Glenorchy, Tasmania 7010

Phone: (03) 6224 4477



DISPLAY CENTRES

MELBOURNE BRICK

227 Princes Highway, Hallam Victoria 3803

MELBOURNE BRICK

330 Tooronga Road, Glen Iris, Victoria 3146

MELBOURNE BRICK

443 Mountain Highway, Bayswater, Victoria 3153

MD BRICK

40 Eddie Road, Minchinbury NSW 2770

MD BRICK

9 Dyer Crescent, West Gosford NSW 2250

AMBER TILES

104 Windsor Road, Kellyville, NSW 2155

AUSTRALIAN PAVING

3 Oborn Road, Mount Barker SA 5251

TYRONE GROUP

102 Erindale Road, Balcatta WA 6021

FREECALL 1800 004 499

email: sales@islandblock.com.au islandblock.com.au

"No one knows Blocks and Pavers better"



